

ESS-ES1869

DEVICE DRIVER and APPLICATION
INSTALLATION

Under


WINDOWS 3.1x

August 1997


ES1869 Device Driver Installation Guide for Windows 3.1x

To install the Device Driver under Windows 3.1x, please follow the steps below:

- 1.) Please start your system Windows 3.1x.
- 2.) Use the "Run" command in the "Program Manager" as the figure shows below.



- 3.) In the "Run" dialog box, please browse to the directory you have extracted the driver files, select **SETUP.EXE** and click the "OK" push button to continue.




- 4.) The "AudioDrive Setup" dialog box will inform you that you must reboot your system for the ES1869 driver to take effect. It is suggested that you close all the application programs before you setup the ES1869 driver. You can click the "Continue" push button to start the setup process, or click the "Exit" push button to quit the program.



5.) Please click the "Driver Installation" push button to continue installing the ES1869 driver. If you are not using a PnP BIOS, follow step 5-1), otherwise go to step 6.).



5-1) In the "Hardware Settings" dialog box shown as below, you can change all the system resources in the list box. You should be aware that these settings should not be in conflict with other devices in your computer. After you have set the system resources, click the "OK" push button to continue.




NOTE: Please note that the figure displayed on the previous page is used as an example and may vary according to the settings of your system.

- 6) Please click the "Reboot System" push button to restart the computer so the ES1869 device driver can take effect.



- 6.) After you have restarted the computer, you can check if the ES1869 driver is installed correctly or not. The figure shown as below will be displayed in the "Control Panel" of the "Main" program group, as an example of a successful installation. Click on the "Drivers"-icon in the System Manager.




NOTE: Please note that the figure displayed above is used as an example and the driver version may vary.

Installation of the AudioRack Software Application

Example for installing the AudioRACK Software Application.

- 7.) Under Windows 3.1x, please use the "Run" command, and browse to the directory you have extracted the setup files and select **SETUP.EXE** . Click the OK push button to continue.



- 2.) Click the "Continue" push button to continue installing the AudioRack .




- 3.) The "AudioRack Setup" dialog box shown as below will inform you that the AudioRack application will be installed to "**C:\AUDRACK**" as the default directory. You can specify a different directory by typing a different name.



4.) Please click the "Complete Installation" to continue the installation.



5.) The figure shown as below indicates that the system is extracting files to the destination directory, please wait for some seconds.




6.) Please click the "Exit" push button to complete the installation.




You can add an Spatial 3D program item to your "AudioRack" program group.


1.) In Windows 3.1x Program Manager, please click the "File" pop up menu, and choose the "New" command. A "New Program Object" will appear as the figure shows below. Please choose the "Program Item" and click the OK push button.



- 2.) In the "Program Item Properties" dialog box, please set the "Description" as you wish (e.g.: 3D), the Command Line (e.g.: Spatial.exe), the Working Directory (e.g.: C:\AUDRACK) then click the OK push button.



- 3.) An 3D program item should appear in the AudioRack program group.



E-20-022
Version 1.0